

**GB** **Forced draught gas burner**

Progressive two-stage or modulating operation

| CODE     | MODEL    | TYPE   |
|----------|----------|--------|
| 20102448 | RS 50/EV | 02448Y |



**Translation of the original instructions**

|          |  |           |
|----------|--|-----------|
| <b>1</b> | <b>Declarations</b> .....                                      | <b>3</b>  |
| <b>2</b> | <b>Information and general warnings</b> .....                  | <b>4</b>  |
| 2.1      | Information about the instruction manual .....                 | 4         |
| 2.1.1    | Introduction.....  | 4         |
| 2.1.2    | General dangers.....   | 4         |
| 2.1.3    | Other symbols .....  | 4         |
| 2.1.4    | Delivery of the system and the instruction manual.....         | 5         |
| 2.2      | Guarantee and responsibility.....                              | 5         |
| <b>3</b> | <b>Safety and prevention</b> .....                             | <b>6</b>  |
| 3.1      | Introduction.....  | 6         |
| 3.2      | Personnel training .....                                       | 6         |
| <b>4</b> | <b>Technical description of the burner</b> .....               | <b>7</b>  |
| 4.1      | Burner designation .....                                       | 7         |
| 4.2      | Models available.....  | 7         |
| 4.3      | Burner categories .....  | 8         |
| 4.4      | Technical data .....   | 8         |
| 4.5      | Electrical data.....   | 9         |
| 4.6      | Maximum dimensions.....  | 9         |
| 4.7      | Firing rate .....  | 10        |
| 4.7.1    | Firing rate based on the air density .....                     | 11        |
| 4.8      | Test boiler.....   | 12        |
| 4.9      | Burner equipment.....  | 12        |
| 4.10     | Burner description .....                                       | 13        |
| 4.11     | AZL Display.....   | 14        |
| 4.12     | Control box for the air/fuel ratio (LMV52...) .....            | 15        |
| 4.13     | Servomotor.....  | 17        |
| <b>5</b> | <b>Installation</b> .....                                      | <b>18</b> |
| 5.1      | Notes on safety for the installation .....                     | 18        |
| 5.2      | Handling .....   | 18        |
| 5.3      | Preliminary checks .....                                       | 18        |
| 5.4      | Operating position .....                                       | 19        |
| 5.5      | Preparing the boiler .....                                     | 19        |
| 5.5.1    | Boring the boiler plate .....                                  | 19        |
| 5.5.2    | Blast tube length.....   | 19        |
| 5.6      | Electrode positioning .....                                    | 19        |
| 5.7      | Securing the burner to the boiler .....                        | 20        |
| 5.7.1    | Introduction.....  | 20        |
| 5.8      | Combustion head adjustment.....                                | 21        |
| 5.9      | Closing the burner .....                                       | 22        |
| 5.10     | Gas feeding .....  | 23        |
| 5.10.1   | Gas feeding line .....   | 23        |
| 5.10.2   | Burner layout .....  | 24        |
| 5.10.3   | Gas train.....   | 24        |
| 5.10.4   | Gas pressure .....   | 25        |
| 5.11     | Electrical wiring .....  | 26        |
| 5.11.1   | Supply cables and external connections passage .....           | 26        |
| <b>6</b> | <b>Start-up, calibration and operation of the burner</b> ..... | <b>27</b> |
| 6.1      | Notes on safety for the first start-up .....                   | 27        |
| 6.2      | Adjustments prior to ignition .....                            | 27        |
| 6.3      | Burner start-up .....  | 28        |
| 6.4      | Burner adjustment.....   | 28        |
| 6.4.1    | Output upon ignition .....                                     | 28        |
| 6.4.2    | Maximum output.....  | 28        |
| 6.4.3    | Minimum output.....  | 28        |
| 6.5      | Final adjustment of the pressure switches .....                | 29        |
| 6.5.1    | Air pressure switch.....                                       | 29        |
| 6.5.2    | Maximum gas pressure switch .....                              | 29        |

|          |   |           |
|----------|---|-----------|
| 6.5.3    | Minimum gas pressure switch.....                              | 30        |
| 6.5.4    | PVP pressure switch kit .....                                 | 30        |
| 6.6      | Ignition failure.....   | 30        |
| 6.7      | Burner flame goes out during operation.....                   | 30        |
| 6.8      | Stopping of the burner .....                                  | 30        |
| 6.9      | Final checks (with burner operating).....                     | 31        |
| <b>7</b> | <b>Maintenance .....</b>                                      | <b>32</b> |
| 7.1      | Notes on safety for the maintenance .....                     | 32        |
| 7.2      | Maintenance programme .....                                   | 32        |
| 7.2.1    | Maintenance frequency.....                                    | 32        |
| 7.2.2    | Checking and cleaning.....                                    | 32        |
| 7.2.3    | Checking the air and gas pressure on the combustion head..... | 33        |
| 7.2.4    | Moving backward of the control box .....                      | 33        |
| 7.3      | Opening the burner .....                                      | 34        |
| 7.4      | Closing the burner.....                                       | 34        |
| <b>8</b> | <b>Faults - Possible causes - Solutions.....</b>              | <b>35</b> |
| <b>A</b> | <b>Appendix - Accessories .....</b>                           | <b>36</b> |
| <b>B</b> | <b>Appendix - Electrical panel layout.....</b>                | <b>37</b> |

## 1 Declarations

### Declaration of Conformity in accordance with ISO / IEC 17050-1


|  |  |                               |
|--|--|-------------------------------|
| Manufacturer:  | RIELLO S.p.A.                              |                               |
| Address:   | Via Pilade Riello, 7<br>37045 Legnago (VR) |                               |
| Product:   | Forced draught gas burners                 |                               |
| Model:   | RS 50/EV                                   |                               |
| These products are in compliance with the following Technical Standards: |  |                               |
| EN 676   |  |                               |
| EN 12100   |  |                               |
| and according to the European Directives:                                |  |                               |
| MD   | 2006/42/EC                                 | Machine Directive             |
| LVD  | 2014/35/UE                                 | Low Voltage Directive         |
| EMC  | 2014/30/UE                                 | Electromagnetic Compatibility |

**The quality is guaranteed by a quality and management system certified in accordance with UNI EN ISO 9001.**

Legnago, 01.12.2015

Executive General Manager  
RIELLO S.p.A. - Burner Department

Mr. U. Ferretti



Research & Development Director  
RIELLO S.p.A. - Burner Department

Mr. F. Comencini



**2 Information and general warnings**

**2.1 Information about the instruction manual**

**2.1.1 Introduction**

The instruction manual supplied with the burner:

- is an integral and essential part of the product and must not be separated from it; it must therefore be kept carefully for any necessary consultation and must accompany the burner even if it is transferred to another owner or user, or to another system. If the manual is lost or damaged, another copy must be requested from the Technical Assistance Service of the area;
- is designed for use by qualified personnel;
- offers important indications and instructions relating to the installation safety, start-up, use and maintenance of the burner.

**Symbols used in the manual**

In some parts of the manual you will see triangular DANGER signs. Pay great attention to these, as they indicate a situation of potential danger.

**2.1.2 General dangers**

The dangers can be of 3 levels, as indicated below.



**Maximum danger level!**  
This symbol indicates operations which, if not carried out correctly, cause serious injury, death or long-term health risks.



This symbol indicates operations which, if not carried out correctly, may cause serious injury, death or long-term health risks.



This symbol indicates operations which, if not carried out correctly, may cause damage to the machine and/or injury to people.

**2.1.3 Other symbols**



**DANGER: LIVE COMPONENTS**  
This symbol indicates operations which, if not carried out correctly, lead to electric shocks with lethal consequences.



**DANGER: FLAMMABLE MATERIAL**  
This symbol indicates the presence of flammable materials.



**DANGER: BURNING**  
This symbol indicates the risks of burns due to high temperatures.



**DANGER: CRUSHING OF LIMBS**  
This symbol indicates the presence of moving parts: danger of crushing of limbs.



**WARNING: MOVING PARTS**  
This symbol indicates that you must keep limbs away from moving mechanical parts; danger of crushing.



**DANGER: EXPLOSION**  
This symbol signals places where an explosive atmosphere may be present. An explosive atmosphere is defined as a mixture - under atmospheric conditions - of air and flammable substances in the form of gases, vapours, mist or dust in which, after ignition has occurred, combustion spreads to the entire unburned mixture.



**PERSONAL PROTECTION EQUIPMENT**  
These symbols indicate the equipment that must be worn and kept by the operator for protection against threats against safety and/or health while at work.



**OBLIGATION TO ASSEMBLE THE COVER AND ALL THE SAFETY AND PROTECTION DEVICES**  
This symbol signals the obligation to reassemble the cover and all the safety and protection devices of the burner after any maintenance, cleaning or checking operations.



**ENVIRONMENTAL PROTECTION**  
This symbol gives indications for the use of the machine with respect for the environment.



**IMPORTANT INFORMATION**  
This symbol indicates important information that you must bear in mind.



This symbol indicates important information that you must bear in mind.

**IMPORTANT**

- This symbol indicates a list.

**Abbreviations used**

|      |         |
|------|---------|
| Ch.  | Chapter |
| Fig. | Figure  |
| Page | Page    |
| Sec. | Section |
| Tab. | Table   |

**2.1.4 Delivery of the system and the instruction manual**

When the system is delivered, it is important that:

- the instruction manual is delivered to the user by the system manufacturer, with the recommendation to keep it in the room where the heat generator is to be installed.
- The instruction manual shows:
  - the serial number of the burner;

.....

- the address and telephone number of the nearest Assistance Centre

.....  
 .....  
 .....

- The system supplier must carefully inform the user about:
  - the use of the system;
  - any further tests that may be required before activating the system;
  - maintenance, and the need to have the system checked at least once a year by a representative of the manufacturer or another specialised technician.
 To ensure a periodic check, the manufacturer recommends the drawing up of a Maintenance Contract.

**2.2 Guarantee and responsibility**

The manufacturer guarantees its new products from the date of installation, in accordance with the regulations in force and/or the sales contract. At the moment of the first start-up, check that the burner is integral and complete.



**WARNING**

Failure to observe the information given in this manual, operating negligence, incorrect installation and carrying out of non authorised modifications will result in the annulment by the manufacturer of the guarantee that it supplies with the burner.

In particular, the rights to the guarantee and the responsibility will no longer be valid, in the event of damage to things or injury to people, if such damage/injury was due to any of the following causes:

- incorrect installation, start-up, use and maintenance of the burner;
- improper, incorrect or unreasonable use of the burner;
- intervention of unqualified personnel;
- carrying out of unauthorised modifications on the equipment;
- use of the burner with safety devices that are faulty, incorrectly applied and/or not working;
- installation of untested supplementary components on the burner;
- powering of the burner with unsuitable fuels;
- faults in the fuel supply system;
- continuation of use of the burner when a fault has occurred;
- repairs and/or overhauls incorrectly carried out;
- modification of the combustion chamber with inserts that prevent the regular development of the structurally established flame;
- insufficient and inappropriate surveillance and care of those burner components most likely to be subject to wear and tear;
- use of non-original components, including spare parts, kits, accessories and optional;
- force majeure.

**The manufacturer furthermore declines any and every responsibility for the failure to observe the contents of this manual.**

### 3 Safety and prevention

#### 3.1 Introduction

The burners have been designed and built in compliance with current regulations and directives, applying the known technical rules of safety and envisaging all the potential danger situations.

It is necessary, however, to bear in mind that the imprudent and clumsy use of the equipment may lead to situations of death risk for the user or third parties, as well as the damaging of the burner or other items. Inattention, thoughtlessness and excessive confidence often cause accidents; the same applies to tiredness and sleepiness.

It is a good idea to remember the following:

- The burner must only be used as expressly described. Any other use should be considered improper and therefore dangerous.

In particular:

it can be applied to boilers operating with water, steam, diathermic oil, and to other uses expressly foreseen by the manufacturer;

the type and pressure of the fuel, the voltage and frequency of the electrical power supply, the minimum and maximum deliveries for which the burner has been regulated, the pressurisation of the combustion chamber, the dimensions of the combustion chamber and the room temperature must all be within the values indicated in the instruction manual.

- Modification of the burner to alter its performance and destinations is not allowed.
- The burner must be used in exemplary technical safety conditions. Any disturbances that could compromise safety must be quickly eliminated.
- Opening or tampering with the burner components is not allowed, apart from the parts requiring maintenance.
- Only those parts envisaged by the manufacturer can be replaced.



The manufacturer guarantees safety and proper functioning only if all burner components are intact and positioned correctly.

#### 3.2 Personnel training

The user is the person, body or company that has acquired the machine and intends to use it for the specific purpose. He is responsible for the machine and for the training of the people working around it.

The user:

- undertakes to entrust the machine exclusively to suitably trained and qualified personnel;
- undertakes to inform his personnel in a suitable way about the application and observance of the safety instructions. With that aim, the user undertakes to ensure that everyone knows the use and safety instructions for his own duties;
- Personnel must follow all the danger and caution indications shown on the machine.
- Personnel must not carry out, on their own initiative, operations or interventions that are not within their province.
- Personnel are obliged to inform their superiors of every problem or dangerous situation that may arise.
- The assembly of parts of other makes, or any modifications, can alter the characteristics of the machine and hence compromise operating safety. The manufacturing company therefore accepts no responsibility whatsoever for any which may result from the use of non-original parts.

In addition:




- must take all the measures necessary to prevent unauthorised people gaining access to the machine;
- the user must inform the manufacturer if faults or malfunctioning of the accident prevention systems are noticed, along with any presumed danger situation;
- personnel must always use the personal protective equipment envisaged by legislation and follow the indications given in this manual.



**4 Technical description of the burner**

**4.1 Burner designation**



**4.2 Models available**

| Designation |    | Power supply voltage  | Start-up         | Code     |
|-------------|----|-----------------------|------------------|----------|
| RS 50/EV    | TC | 3 ~ 400 / 230V - 50Hz | Direct/ Inverter | 20102448 |

Tab. A

**4.3 Burner categories**

| Country of destination                                     | Gas category |
|--|--------------|
| BE   | I2E(R)       |
| LV   | I2H          |
| CY, MT   | I3B/P        |
| BE   | I3P          |
| LU, PL   | II2E3B/P     |
| DE   | II2ELL3B/P   |
| FR   | II2Er3P      |
| AT, CH, CZ, DK, EE, FI, GR, HU, IS, IT, LT, NO, SE, SI, SK | II2H3B/P     |
| ES, GB, IE, PT   | II2H3P       |
| NL   | II2L3B/P     |

**Tab. B**
**4.4 Technical data**

| Model                      |      | RS 50/EV     |  |
|----------------------------|------|--------------|--|
| Output <sup>(1)</sup>      | Max. | kW<br>Mcal/h | 290 - 580<br>250 - 499   |
|                            | Min. | kW<br>Mcal/h | 116<br>100   |
| Fuel                       |      |              | BIOGAS <sup>(5)</sup>  |
| Operation                  |      |              | <ul style="list-style-type: none"> <li>- Intermittent (min. 1 stop in 24 hours)</li> <li>- Modulating</li> </ul> |
| Standard applications      |      |              | Boilers: water, steam, diathermic oil  |
| Ambient temperature        |      | °C           | 0 - 40   |
| Combustion air temperature |      | °C max       | 60   |
| Noise level <sup>(3)</sup> |      | dB(A)        | 72   |
|                            |      |              | 83   |
| Weight <sup>(4)</sup>      |      | kg           | 45   |

**Tab. C**

<sup>(1)</sup> Reference conditions: Ambient temperature 20°C - Gas temperature 15°C - Barometric pressure 1,013 mbar - Altitude 0 m a.s.l.

<sup>(2)</sup> Gas pressure on the pipe coupling test point 20)(Fig. 5 on page 13) with 0 mbar in the combustion chamber and at maximum burner output.

<sup>(3)</sup> Sound pressure measured in manufacturer's combustion laboratory, with burner operating on test boiler and at maximum rated output. The sound power is measured with the "Free Field" method, as per EN 15036, and according to an accurate "Accuracy: Category 3" measurement, as described in EN ISO 3746.

<sup>(4)</sup> The burner is factory set for FS1 operation (1 stop every 24 hours); it can be converted to FS2 operation (continuous - 1 stop every 72 hours), by changing the parameters using the menu of the AZL Display.

<sup>(5)</sup> Biogas composition:

|                       |        |
|-----------------------|--------|
| <b>CH<sub>4</sub></b> | 65%    |
| <b>CO<sub>2</sub></b> | 33.5%  |
| <b>N<sub>2</sub></b>  | 0.8%   |
| <b>O<sub>2</sub></b>  | 0.4%   |
| <b>H<sub>2</sub>S</b> | 0.3%   |
| <b>NH<sub>3</sub></b> | 0.005% |

**4.5 Electrical data**

| Model                               |         | RS 50/EV                    |  |
|-------------------------------------|---------|-----------------------------|--|
| Main electrical supply              |         | 3 ~ 400 / 230V +/-10% 50 Hz |  |
| Auxiliary circuit electrical supply |         | 1N 230V ~ +/-10% 50/60Hz    |  |
| Fan motor                           | Hz      | 50                          |  |
|                                     | rpm     | 2,800                       |  |
|                                     | V       | 220/240 - 380/415           |  |
|                                     | kW      | 0.65                        |  |
|                                     | A       | 3 - 1.7                     |  |
| Ignition transformer                | V1 - V2 | 230V - 1x8 kV               |  |
|                                     | I1 - I2 | 1A - 20 mA                  |  |
| Absorbed electrical power           | kW max  | 1.09                        |  |
| Protection level                    |         | IP 44                       |  |

Tab. D

**4.6 Maximum dimensions**

The maximum dimensions of the burner are given in Fig. 1.

The dimensions of the open burner are indicated by position H.

Bear in mind that inspection of the combustion head requires the burner to be opened and the rear part drawn back on the slide bars.




Fig. 1

| mm       | A   | B   | C   | D   | E   | F   | G   | H   | I   | L   | M     |
|----------|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-------|
| RS 50/EV | 684 | 534 | 507 | 356 | 150 | 354 | 171 | 884 | 110 | 168 | 1"1/2 |

Tab. E


**4.7 Firing rate**

The maximum output is chosen within area A (Fig. 2).

The minimum output must not be lower than the minimum limit of the diagram.



The firing rate value (Fig. 2) has been obtained considering an ambient temperature of 20 °C, an atmospheric pressure of 1,013 mbar (approx. 0 m a.s.l.), and with the combustion head adjusted as shown on pag. 21.

**Fig. 2**

**4.7.1 Firing rate based on the air density**

The firing rate of the burner indicated in the manual refers to an ambient temperature of 20°C and an altitude of 0 m. above sea level. (barometric pressure about 1013 mbar).

It may happen that a burner has to operate with combustion air at a higher temperature and/or higher altitudes.

The heating of the air and the increase in altitude produce the same effect: the expansion of the air volume (i.e. the reduction of its density).

The delivery of the burner fan remains essentially the same, but the oxygen per m3 of air, and the thrust (discharge head) of the fan are reduced.

It is therefore important to know if the maximum output requested from the burner at a determinate combustion chamber pressure remains within the firing rate of the burner even with the changed temperature and altitude conditions.

To check it, proceed as follows:

- 1 find the corrective factor F, relating to the air temperature and altitude of the system, in Tab. F.
- 2 Divide the output Q required from the burner by F to obtain the equivalent output Qe:

$$Q_e = Q : F \text{ (kW)}$$

- 3 In the firing rate of the burner, mark the work point identified by:

Qe = equivalent output

H1 = pressure in combustion chamber point A that must remain within the firing rate.

- 4 Trace a vertical line from point A) (Fig. 3), and find the maximum pressure H2 of the firing rate.
- 5 Multiply H2 by F to obtain the maximum lowered pressure H3 of the firing rate:

$$H_3 = H_2 \times F \text{ (mbar)}$$

If H3 is greater than H1)(Fig. 3), the burner can supply the required output.

If H3 is less than H1, it is necessary to reduce the burner output. The reduction in output is accompanied by a reduction in combustion chamber pressure:

Qr = reduced output

H1r = reduced pressure

$$H_{1r} = H_1 \times \left( \frac{Q_r}{Q} \right)^2$$

Example, 5% reduction in output:

$$Q_r = Q \times 0.95$$

$$H_{1r} = H_1 \times (0.95)^2$$

With the new values - Qr and H1r - repeat steps 2 - 5.



The combustion head should be adjusted in relation to the equivalent output Qe.




Fig. 3

| Altitude  | Average barometric pressure | F                  |       |       |       |       |       |       |       |
|-----------|-----------------------------|--------------------|-------|-------|-------|-------|-------|-------|-------|
|           |                             | Air temperature °C |       |       |       |       |       |       |       |
| m. a.s.l. | mbar                        | 0                  | 5     | 10    | 15    | 20    | 25    | 30    | 40    |
| 0         | 1,013                       | 1.087              | 1.068 | 1.049 | 1.031 | 1.013 | 0.996 | 0.980 | 0.948 |
| 100       | 1,000                       | 1.073              | 1.054 | 1.035 | 1.017 | 1.000 | 0.983 | 0.967 | 0.936 |
| 200       | 989                         | 1.061              | 1.042 | 1.024 | 1.006 | 0.989 | 0.972 | 0.956 | 0.926 |
| 300       | 978                         | 1.050              | 1.031 | 1.013 | 0.995 | 0.978 | 0.962 | 0.946 | 0.916 |
| 400       | 966                         | 1.037              | 1.018 | 1.000 | 0.983 | 0.966 | 0.950 | 0.934 | 0.904 |
| 500       | 955                         | 1.025              | 1.007 | 0.989 | 0.972 | 0.955 | 0.939 | 0.923 | 0.894 |
| 600       | 944                         | 1.013              | 0.995 | 0.977 | 0.960 | 0.944 | 0.928 | 0.913 | 0.884 |
| 700       | 932                         | 1.000              | 0.982 | 0.965 | 0.948 | 0.932 | 0.916 | 0.901 | 0.872 |
| 800       | 921                         | 0.988              | 0.971 | 0.954 | 0.937 | 0.921 | 0.906 | 0.891 | 0.862 |
| 900       | 910                         | 0.977              | 0.959 | 0.942 | 0.926 | 0.910 | 0.895 | 0.880 | 0.852 |
| 1,000     | 898                         | 0.964              | 0.946 | 0.930 | 0.914 | 0.898 | 0.883 | 0.868 | 0.841 |
| 1,200     | 878                         | 0.942              | 0.925 | 0.909 | 0.893 | 0.878 | 0.863 | 0.849 | 0.822 |
| 1,400     | 856                         | 0.919              | 0.902 | 0.886 | 0.871 | 0.856 | 0.842 | 0.828 | 0.801 |
| 1,600     | 836                         | 0.897              | 0.881 | 0.866 | 0.851 | 0.836 | 0.822 | 0.808 | 0.783 |
| 1,800     | 815                         | 0.875              | 0.859 | 0.844 | 0.829 | 0.815 | 0.801 | 0.788 | 0.763 |
| 2,000     | 794                         | 0.852              | 0.837 | 0.822 | 0.808 | 0.794 | 0.781 | 0.768 | 0.743 |
| 2,400     | 755                         | 0.810              | 0.796 | 0.782 | 0.768 | 0.755 | 0.742 | 0.730 | 0.707 |
| 2,800     | 714                         | 0.766              | 0.753 | 0.739 | 0.726 | 0.714 | 0.702 | 0.690 | 0.668 |
| 3,200     | 675                         | 0.724              | 0.711 | 0.699 | 0.687 | 0.675 | 0.664 | 0.653 | 0.632 |
| 3,600     | 635                         | 0.682              | 0.669 | 0.657 | 0.646 | 0.635 | 0.624 | 0.614 | 0.594 |
| 4,000     | 616                         | 0.661              | 0.649 | 0.638 | 0.627 | 0.616 | 0.606 | 0.596 | 0.577 |

Tab. F

**4.8 Test boiler**


The firing rates were set in relation to special test boilers, according to EN 676 regulations.

In Fig. 4 you can see the diameter and length of the test combustion chamber.

Example:

Output 407 kW (350 Mcal/h) - diameter 50 cm, length 1.5 m.

The coupling is ensured when the boiler is EC type-approved; for boilers or ovens with combustion chambers of very different dimensions compared to those shown in the diagram of (Fig. 4) preliminary checks are recommended.




**Fig. 4**

**4.9 Burner equipment**

The burner is supplied complete with:

- Gas train flange . . . . . No. 1
- Gasket for gas train flange . . . . . No. 1
- Thermal insulation screen . . . . . No. 1
- Flange fixing screws M8 x 25 . . . . . No. 4
- M8 x 25 screws for fixing the burner flange to the boiler . . . . . No. 4
- Cable grommets for electrical wiring . . . . . No. 4
- CANBUS cable kit (10 mt.) . . . . . No. 1
- Oxygen control kit . . . . . No. 1
- Instructions . . . . . No. 1
- Spare parts list . . . . . No. 1

4.10 Burner description



20104932

Fig. 5

- |    |  |    |                                      |
|----|--|----|--------------------------------------|
| 1  | Combustion head  | 27 | Auxiliary fuse                       |
| 2  | Ignition electrode   | 28 | ON/OFF selector                      |
| 3  | Screw for combustion head adjustment                                 | 29 | Light signalling of mains live state |
| 4  | Pipe coupling  | 30 | Heat request indicator light         |
| 5  | Minimum air pressure switch (differential operating type)            | 31 | Maximum gas pressure switch          |
| 6  | Air pressure test point on the head                                  | 32 | Transformer for control box          |
| 7  | Gas pressure test point and head fixing screw                        | 33 | Terminal board for electrical wiring |
| 8  | Screw securing fan to pipe coupling                                  | 34 | Holes for electrical wiring input    |
| 9  | Slide bars for opening the burner and inspecting the combustion head | 35 | Rings for lifting                    |
| 10 | Light signalling burner on   | 36 | Clean contact relay                  |
| 11 | Terminal board X2  | 37 | Rpm sensor                           |
| 12 | Ignition transformer   | 38 | Pressure test point "+"              |
| 13 | Filter to protect against radio disturbance                          | 39 | Operator panel with LCD display      |
| 14 | QRI probe  | 40 | Gas servomotor plug/socket           |
| 15 | Holes for electrical wiring input                                    | 41 | gas servomotor                       |
| 16 | Fan air inlet  | 42 | Holes for electrical wiring input    |
| 17 | Gas input pipe   | 43 | Earth screws                         |
| 18 | Boiler fixing flange   |    |                                      |
| 19 | Flame stability disk   |    |                                      |
| 20 | Flame inspection window  |    |                                      |
| 21 | Luminous push-button for reset                                       |    |                                      |
| 22 | XPLL terminal board  |    |                                      |
| 23 | LMV control box  |    |                                      |
| 24 | LOCAL-REMOTE selector  |    |                                      |
| 25 | Fan motor  |    |                                      |
| 26 | Air pressure test point "-"  |    |                                      |

4.11 AZL Display...

**Warnings**



To avoid accidents, material or environmental damage, observe the following instructions!

The AZL... display is a safety device! Avoid opening or modifying it, or forcing its operation. Riello S.p.A. cannot assume any responsibility for damage resulting from unauthorised interventions!

The electronic cam is operated and programmed through the AZL5 interface... or with the aid of a PC.

The AZL5 has a backlit LCD display with clear reading of the menu text and diagnostics.

The Modbus function of the AZL display integrates the electronic cam LMV5 and through data management allows the diagnostic of the burner.

The display shows the operating status, the types of errors and lockouts. Used to parameterize and monitor data.



**Fig. 6**

**Technical data**

|                                   |   |
|-----------------------------------|---|
| Operating voltage                 | AC 24 V - 15% / +10%                                |
| Power consumption                 | < 5W (typical)                                      |
| Protection level of the container |   |
| - Rear                            | IP00 according to IEC 529                           |
| - Front                           | IP54 according to IEC 529 (if installed)            |
| Safety class                      | I with parts II and III according to DIN EN 60730-1 |
| <b>Battery - Manufacturer:</b>    | <b>Type reference:</b>                              |
| VARTA                             | CR 2430 (LF-1/2 W)                                  |
| DURACELL                          | DL 2430   |
| SANYO ELECTRIC, Osaka/ Japan      | CR 2430 (LF-1/2 W)                                  |
| RENATA AG, Itingen/CH             | CR 2430   |

**Tab. G**



**4.12 Control box for the air/fuel ratio (LMV52...)**

**Warnings**



To avoid accidents, material or environmental damage, observe the following instructions!

The LMV52 control box... is a safety device! Avoid opening or modifying it, or forcing its operation. Riello S.p.A. cannot assume any responsibility for damage resulting from unauthorised interventions!

**Risk of explosion!**

An incorrect configuration can provoke fuel overcharging, with the consequential risk of explosion! Operators must be aware that incorrect settings made on the AZL5... display and operating unit and incorrect settings of the fuel and / or air actuator positions can lead to dangerous burner operating conditions.

- All interventions (assembly and installation operations, assistance, etc.) must be carried out by qualified personnel.
- Before modifying the wiring in the LMV52 control box connection area, fully disconnect the system from the power supply (omnipolar separation). Check the system is not powered and cannot be accidentally reconnected. Failure to do this will lead to the risk of electrocution.
- Protection against electrocution from the LMV5... control box and all connected electric components is obtained with correct assembly.
- Before any intervention (assembly and installation operations, assistance, etc.), ensure the wiring is in order and that the parameters are correctly set, then make the safety checks.
- Falls and collisions can negatively affect the safety functions.

In this case, the control box must not be operated, even if it displays no evident damage.

- In programming mode, the position check of actuators and VSD (checking electronic fuel / air ratio control) is different from the check during automatic operation.

As for automatic operation, the actuators are guided together to the positions requested and, if an actuator does not reach the position requested, adjustments are made until the position is actually reached. However, in contrast to automatic operation, there are no time limits to these corrective actions.

The other actuators maintain their positions until all actuators have reached the positions currently required.

This is absolutely important to set the fuel / air ratio control system.

During the time the fuel / air ratio curves are being programmed, the person making the plant settings must continuously monitor the quality of the combustion process (e.g. by means of a flue gas analyser).

Also, if combustion levels are poor, or in the event of dangerous situations, the commissioning engineer must take appropriate action (e.g. switching off manually).

To ensure the safety and reliability of the LMV5... system, the following instructions must also be followed:

- avoid conditions that can favour the development of condensate and humidity. Otherwise, before switching on again, make sure that the entire control box is perfectly dry!
- Static charges must be avoided since they can damage the control box's electronic components when touched.



D9301

**Fig. 7**

**Mechanical structure**

The LMV5... control box is a system to check the burners, based on a microprocessor and equipped with components to adjust and monitor medium and large capacity forced draught burners. The base control box of the LMV5... system incorporates the following components:

- Burner adjustment device with system for checking the seal of the gas valves
- Electronic device to check the fuel/air ratio with a maximum of 6 actuators
- Optional PID temperature / pressure controller (load controller)
- Optional VSD module Mechanical design

**Installation notes**

- Check the electric wiring inside the boiler complies with the national and local safety regulations.
- Do not confuse the powered conductors with the neutral ones.
- Make sure the cable grommets of the connected cables comply with the relevant standards (e.g. DIN EN 60730 and DIN EN 60 335).
- Ensure that spliced wires cannot get into contact with neighbouring terminals. Use adequate ferrules.
- Arrange the H.V. ignition cables separately, as far as possible from the control box and the other cables.
- The burner manufacturer must protect unused AC 230V terminals with dummy plugs (refer to sections Suppliers of other accessory items).
- When wiring the unit, make sure that AC 230V mains voltage cables are run strictly separate from extra low-voltage cables to avoid risks of electrical shock hazard.

### Electrical wiring of the flame detector

It is important for signal transmission to be almost totally free of any disturbances or loss:

- always separate the detector cables from the other cables:
  - Line capacitance reduces the magnitude of the flame signal.
  - Use a separate cable.
- Respect the allowed cable lengths.

### Technical data

|  |  |   |                     |
|--|--|---|---------------------|
| LMV52... base control box  | Mains voltage  | AC 230V -15% / +10%   |                     |
|  | Mains frequency  | 50 / 60 Hz $\pm$ 6%   |                     |
|  | Power absorption   | < 30W (normal)  |                     |
|  | Safety class   | I, with components in compliance with II and III, according to DIN EN 60730-1 |                     |
| Load on 'input' terminals  | F1 unit fuse (internal)                                      | 6.3 AT  |                     |
|  | Primary perm. mains fuse (external)                          | Max. 16 AT  |                     |
|  | Undervoltage   |   |                     |
|  | • Safety switch-off from operating position to mains voltage | < AC 186V   |                     |
|  | • Restart when mains voltage picks up                        | > AC 188V   |                     |
|  | Oil pump / magnetic clutch (nominal voltage)                 |   |                     |
| • Nominal current  |  |   |                     |
| • Power factor   | 2A<br>$\cos\phi > 0.4$                                       |   |                     |
| Air pressure switch test valve (nominal voltage)                     | • Nominal current  | 0.5A  |                     |
|  | • Power factor   | $\cos\phi > 0.4$  |                     |
|  | Load on 'output' terminals                                   | <b>Total load on the contacts:</b>  |                     |
|  |  | • Mains voltage   | AC 230V -15% / +10% |
| • Total unit input current (safety circuit) load on contacts due to: |  | Max. 5 A  |                     |
| - Fan motor contactor  |  |   |                     |
| - Ignition transformer   |  |   |                     |
| - Valve  |  |   |                     |
| - Oil pump / magnetic clutch   |  |   |                     |
| <b>Single contact loading:</b>                                       | Fan motor contactor (nominal voltage)                        |   |                     |
|  | • Nominal current  | 1A  |                     |
|  | • Power factor   | $\cos\phi > 0.4$  |                     |
|  | Alarm output (nominal voltage)                               |   |                     |
|  | • Nominal current  | 1A  |                     |
|  | • Power factor   | $\cos\phi > 0.4$  |                     |
|  | Ignition transformer (nominal voltage)                       |   |                     |
|  | • Nominal current  | 2A  |                     |
|  | • Power factor   | $\cos\phi > 0.2$  |                     |
|  | Fuel gas valve (nominal voltage)                             |   |                     |
|  | • Nominal current  | 2A  |                     |
|  | • Power factor   | $\cos\phi > 0.4$  |                     |
|  | Fuel oil valve (nominal voltage)                             |   |                     |
|  | • Nominal current  | 1A  |                     |
|  | • Power factor   | $\cos\phi > 0.4$  |                     |
| Cable length   | Main line  | Max. 100 m (100 pF / m)   |                     |
| Environmental conditions   | Operation  | DIN EN 60721-3-3  |                     |
|  | Climatic conditions  | Class 3K3   |                     |
|  | Mechanical conditions  | Class 3M3   |                     |
|  | Temperature range  | -20...+60°C   |                     |
|  | Humidity   | < 95% RH  |                     |

Tab. H

4.13 Servomotor

Warnings



WARNING

To avoid accidents, material or environmental damage, observe the following instructions!

**Avoid opening, modifying or forcing the actuators.**

- All interventions (assembly and installation operations, assistance, etc.) must be carried out by qualified personnel.
- Before modifying the wiring in the SQM4... system connection area, fully disconnect the burner control device from the power supply (omnipolar separation).
- To avoid the risk of electrocution, protect the connection terminals in a suitable manner and correctly fix the cover.
- Check the wiring is in order.
- Falls and collisions can negatively affect the safety functions. In this case, the unit must not be operated, even if it displays no evident damage.

Assembly notes

- Check the relevant national safety standards are respected.
- The connection between the actuator command shaft and the control element must be rigid, without any mechanical play.
- To avoid an excessive load on the bearings due to rigid hubs, the use of compensation clutches without any mechanical play is recommended (e.g. metal bellows-type clutches).

Installation notes

- Arrange the H.V. ignition cables separately, as far as possible from the control box and the other cables.
- To avoid the risk of electrocution, make sure that the 230V AC section of the SQM4... unit is fully separated from the functional low-voltage section.
- The static torque is reduced when the electrical supply of the actuator is switched off.
- The housing cover may only be removed for short periods of time for wiring or when making the addressing. In similar cases, make sure that dust or dirt does not penetrate inside the actuator.
- The actuator comprises a PCB with ESD-sensitive components.
- The top side of the board carries a cover which affords protection against direct contact. This protective cover must not be removed! The underside side of the board must not be touched.



WARNING

**During the maintenance or replacement of the actuators, be careful not to invert the connectors.**




Fig. 8

Technical data

|                             |   |
|-----------------------------|---|
| Operating voltage           | AC 2 x 12V via bus cable from the base unit or via a separate transformer |
| Safety class                | extra low-voltage with safe isolation from mains voltage                  |
| Power absorption            |   |
| – SQM45...                  | 9...15 VA   |
| Degree of protection        | to EN 60 529, IP 54, provided adequate cable entries are used             |
| Cable connection            | RAST3,5 connectors  |
| Rotation direction          | - Anticlockwise (standard)<br>- Clockwise (inverted rotation)             |
| Rated torque (max.)         |   |
| – SQM45...                  | 3 Nm  |
| Static torque (max.)        |   |
| – SQM45...                  | 1.5 Nm  |
| Running time (min.) for 90° |   |
| – SQM45...                  | 10 s.   |
| Weight                      |   |
| – SQM45...                  | approx. 1 kg  |
| Environmental conditions:   |   |
| Operation                   | DIN EN 60 721-3-3   |
| Climatic conditions         | Class 3K3   |
| Mechanical conditions       | Class 3M3   |
| Temperature range           | -20...+60°C   |
| Humidity                    | < 95% RH  |

Tab. I



WARNING

Condensation, the formation of ice and the entry of water are prohibited!

**5 Installation**

**5.1 Notes on safety for the installation**

After carefully cleaning all around the area where the burner is to be installed, and arranging for the environment to be illuminated correctly, proceed with the installation operations.



All the installation, maintenance and disassembly operations **MUST** be carried out with the electricity supply disconnected.



The installation of the burner must be carried out by qualified personnel, as indicated in this manual and in compliance with the standards and regulations of the laws in force.



Combustion air inside the boiler must be free from hazardous mixes (e.g.: chloride, fluoride, halogen); if present, it is highly recommended to carry out cleaning and maintenance more frequently.

**5.2 Handling**

The burner is shipped in cardboard packaging, so it is possible to move it when it is still packaged with a transpallet or fork lift truck.



The handling operations for the burner can be highly dangerous if not carried out with the greatest attention: keep any unauthorised people at a distance; check the integrity and suitability of the available means of handling. Check also that the area in which you are working is empty and that there is an adequate escape area (i.e. a free, safe area to which you can quickly move if the burner should fall). When handling, keep the load at not more than 20-25 cm from the ground.



After positioning the burner near the installation point, correctly dispose of all residual packaging, separating the various types of material.



Before proceeding with the installation operations, carefully clean all around the area where the burner will be installed.

**5.3 Preliminary checks**


**Checking the consignment**



After removing all the packaging, check the integrity of the contents. In the event of doubt, do not use the burner; contact the supplier.



The packaging elements (wooden cage or cardboard box, nails, clips, plastic bags, etc.) must not be abandoned as they are potential sources of danger and pollution; they should be collected and disposed of in the appropriate places.

|  |   |   |                                    |
|--|---|---|------------------------------------|
| RBL  | A | B | C                                  |
| D  | E |   | F                                  |
| GAS-KAASU <input checked="" type="checkbox"/>  | G | H |                                    |
| GAZ-AEFO   | G | H |                                    |
| I  |   |   | RIELLO SpA<br>I-37045 Legnago (VR) |
|  |   |   | CE 0085                            |

D7738

**Fig. 9**

**Checking the characteristics of the burner**

Check the burner identification label (Fig. 9), showing:

- A the burner model
- B the burner type
- C the cryptographic year of manufacture
- D the serial number
- E the data for electrical supply and the protection level
- F the electrical power consumption
- G the types of gas used and the relative supply pressures
- H the data of the burner's possible minimum and maximum output (see Firing rate).  
Warning: the burner output must be within the boiler's firing rate;
- I the category of the appliance/countries of destination.



A burner label, or any other component, that has been tampered with, removed or is missing, prevents the definite identification of the burner and makes any installation or maintenance work difficult

**5.4 Operating position**



- The burner is designed to operate only in positions 1, 2, 3 and 4 (Fig. 10).
- Installation 1 is preferable, as it is the only one that allows the maintenance operations as described in this manual.
- Installations 2, 3 and 4 allow operations to be performed, but make maintenance and inspection of the combustion head more difficult.



- Any other position could compromise the correct operation of the appliance.
- Installation 5 is prohibited for safety reasons.




Fig. 10

**5.5 Preparing the boiler**

**5.5.1 Boring the boiler plate**


Pierce the closing plate of the combustion chamber, as in Fig. 11. The position of the threaded holes can be marked using the thermal insulation screen supplied with the burner.

**5.5.2 Blast tube length**

The length of the blast tube must be selected according to the indications provided by the manufacturer of the boiler, and in any case it must be greater than the thickness of the boiler door complete with its fettling.

The lengths L available are:

| Blast tube | (mm) |
|------------|------|
| RS 50/EV   | 351  |



Tab. J

Fig. 11

| mm       | A   | B   | C   |
|----------|-----|-----|-----|
| RS 50/EV | 160 | 224 | M 8 |

Tab. K

**5.6 Electrode positioning**



Before fixing the burner to the boiler, check from the opening of the blast tube that the electrode is correctly positioned, as in Fig. 12.

If the probe or electrode is not correctly positioned, you must:

- remove the screw 1)(Fig. 14)
- take out the inner part 2)(Fig. 14) of the head, and then calibrate them.



Respect the dimensions shown in Fig. 12.




Fig. 12

**5.7 Securing the burner to the boiler**

**5.7.1 Introduction**


The RS 50/EV burner is suitable for operating on both flame inversion boilers\* (in this case the long head model is recommended) and on boilers with a combustion chamber with bottom runoff (three flue gas circulations), from which the best results of low NOx emissions are obtained (Fig. 13).

The maximum thickness of the front door of the boiler (see position "a", Fig. 10), complete with refractory, should not exceed 200 mm.

For boilers with front flue passes 13)(Fig. 15), a protection in refractory material 11) must be inserted between the boiler refractory 12) and the blast tube 10).


This protective fettling must not compromise the extraction of the blast tube.

For boilers with a water-cooled front piece, a refractory lining 11)-12)(Fig. 15) is not necessary, unless expressly requested by the boiler manufacturer.



D1079

**Fig. 13**



**Fig. 14**



Provide an adequate lifting system of the burner.


Separate the combustion head from the rest of the burner, as shown in Fig. 14; proceed as follows:

- loosen the screw 3) and remove the hood 1);
- remove screws 2) from the two slide bars 5);
- disconnect the plugs 14);
- remove the screw 4);
- pull back the burner on the slide bars 5) by about 100 mm;
- disconnect the wires of the electrode and then pull the burner completely off the slide bars, after removing the split pin from the slide bar 5).
- fix the flange 9) to the boiler plate interposing the insulating gasket 8) that has been supplied.
- use the 4 screws supplied, with a tightening torque of 35 - 40 Nm, after protecting their thread with anti-seizing products.



**WARNING**

The burner-boiler seal should be airtight; after starting the burner check that there are no leaks of no flue gases.



20105408

**Fig. 15**



**5.8 Combustion head adjustment**

At this point of the installation, the combustion head is fixed to the boiler as shown in Fig. 14.

Adjusting the air or the gas of the combustion head is especially easy.

In the diagram (Fig. 16), based on the MAX output, find the notch for adjusting both the air and the gas.

**Air adjustment**

Turn the screw 4)(Fig. 17) until the notch found lines up with the front surface 5) of the flange.



To facilitate the adjustment, loosen the screw 6) (Fig. 17), adjust, then block.

**Central gas adjustment**

In adjusting the central gas there are two possible cases:

**1 the MINIMUM output of the burner is less than 130 kW**



When the MIN modulation output is between 116 - 129 kW, the ring nut 2)(Fig. 17) should be adjusted to 0, regardless of the MAX output of the burner.

**2 The MINIMUM output of the burner is greater than 130 kW**

Loosen the screw 1)(Fig. 17) and rotate the ring nut 2) until the notch you have found with the index 3), then lock the screw 1).

**Example:**

the burner varies its output between MIN = 130 and MAX = 460 kW. The gas and air adjustments are carried out on notch 3, as in Fig. 17. The loss of pressure in the combustion head is shown in column 1 Tab. L on page 25.

**NOTE:**

The diagram shows the ideal settings for the ring nut 2).


If the pressure in the power supply network is very low and does not allow the pressure indicated on pag. 25 to be reached at MAX output, and if the ring nut 2) is only partially opened, it is possible to further open the ring nut by 1-2 notches.

Continuing on from the previous example, on pag. 25 we can see that a burner with a 450 kW output requires about 10.5 mbar of pressure at test point 6).


If this pressure is not available, open the ring nut 2) to notch 4-5.



Check that the combustion is satisfactory and without pulsations.



**Fig. 16**



**Fig. 17**

### 5.9 Closing the burner


Once the combustion head adjustment is completed:

- reassemble the burner on the guides 3) at about 100 mm from the pipe coupling 4), burner in the position shown in Fig. 15;
- insert the electrode cable, then slide the burner as far as the pipe coupling, with the burner in the position shown in Fig. 18;
- connect the servomotor plug 14)(Fig. 15) and tighten the cable grommet 15);
- refit the screws 2) and the split pin on the guides 3);
- fix the burner to the pipe coupling with the screw 1).



**WARNING**

On closing the burner on the two guides, it is advisable to gently pull the high voltage cable outwards until it is slightly taut.



20105218

**Fig. 18**



**5.10 Gas feeding**



Explosion danger due to fuel leaks in the presence of a flammable source.

Precautions: avoid knocking, attrition, sparks and heat.

Make sure the fuel interception tap is closed before performing any operation on the burner.



**WARNING**


The fuel supply line must be installed by qualified personnel, in compliance with current standards and laws.

**5.10.1 Gas feeding line**

Key (Fig. 19 - Fig. 20 - Fig. 21 - Fig. 22)

- 1 Gas input pipe
- 2 Manual valve
- 3 Vibration damping joint
- 4 Pressure gauge with push-button cock
- 5 Filter
- 6A Includes:
  - filter
  - safety valve
  - pressure adjuster
  - working valve
- 6C Includes:
  - safety valve
  - working valve
- 6D Includes:
  - safety valve
  - working valve
- 6E Includes:
  - safety valve
  - operation valve with pressure adjuster
- 7 Minimum gas pressure switch
- 8 Leak detection control, provided as an accessory or integrated, based on the gas train code. In compliance with the EN 676 standard, gas valve leak detection control devices are compulsory for burners with maximum outputs over 1,200 kW.
- 9 Gasket, for "flanged" versions only
- 10 Pressure adjuster
- 11 Train-Burner adaptor, supplied separately
- 12 Pressure gas switch for leak detection control
- P2 Upstream pressure of valves/adjuster
- P3 Upstream pressure of the filter
- L Gas train, supplied separately
- L1 The responsibility of the installer


**MB**



20057264

**Fig. 19**


**MBC**



20062223

**Fig. 20**


**DMV**



20062227

**Fig. 21**


**CB**



20062228

**Fig. 22**


**VRD**



20106983

**Fig. 23**

**5.10.2 Burner layout**



**Fig. 24**

**Key (Fig. 24)**

- MV Fan motor
- M Motor
- SM Servomotor
- AD Air damper
- V Fan
- RG Gas valve adjuster (butterfly)
- VTR Adjusting screw for combustion head
- PA Air pressure switch
- PG Max. gas pressure switch
- FR Photocell



The operator must use the required equipment during installation.

**5.10.3 Gas train**

Approved according to standard EN 676 and provided separately from the burner.

To select the correct gas train model, refer to the supplied "Burner-gas train combination" manual.

The train can enter the burner from the right or left side, depending on which is the most convenient, see Fig. 25.

The gas train must be connected to the gas connection 1)(Fig. 25), using the flange 2), the gasket 3) and the screws 4) supplied with the burner.



**WARNING**

The gas solenoids must be as close as possible to the burner to ensure that the gas reaches the combustion head within the safety time of 3s.

Ensure that the maximum pressure to the burner is within the calibration range of the pressure adjuster.

See the accompanying instructions for the adjustment of the gas train.



**DANGER**

Disconnect the electrical power using the main switch.




Check that there are no gas leaks.



Pay attention when handling the train: danger of crushing of limbs.



Make sure that the gas train is properly installed by checking for any fuel leaks.



**Fig. 25**

**5.10.4 Gas pressure**

Tab. L indicates the pressure drop of the combustion head and the gas butterfly valve depending on the operating output of the burner.

| kW  | 1 Δp (mbar) |     | 2 Δp (mbar) |     |
|-----|-------------|-----|-------------|-----|
|     | Town gas    |     | Biogas      |     |
| 290 | 4.6         | 1.3 | 4.4         | 1.2 |
| 330 | 6.1         | 1.7 | 5.8         | 1.6 |
| 370 | 7.5         | 2.2 | 7.1         | 2.1 |
| 410 | 9.0         | 2.6 | 8.6         | 2.5 |
| 450 | 10.5        | 3.0 | 10.0        | 2.9 |
| 490 | 11.7        | 3.9 | 11.1        | 3.7 |
| 530 | 13.2        | 4.3 | 12.5        | 4.1 |
| 580 | 15.1        | 5.2 | 14.3        | 4.9 |

**Tab. L**

The values shown in Tab. L refer to:

- Biogas 6.4 kWh/Sm<sup>3</sup> (5.5 Mcal/Sm<sup>3</sup>)

Column 1

Combustion head pressure drop.

Gas pressure measured at test point 1)(Fig. 26), with:

- combustion chamber at 0 mbar;
- burner working at maximum output

Column 2

Pressure loss at gas butterfly valve 2)(Fig. 26) with maximum opening: 90°.

To calculate the approximate output at which the burner operates:

- subtract the pressure in combustion chamber from the gas pressure measured at test point 1)(Fig. 26).
- Find, in Tab. L related to the burner concerned, the pressure value closest to the result of the subtraction.
- Read off the corresponding output on the left.

**Example:**

Maximum output operation

$$\begin{aligned}
 \text{Gas pressure at test point 1)(Fig. 26)} &= 12 \text{ mbar} \\
 \text{Pressure in combustion chamber} &= 2 \text{ mbar} \\
 12 - 2 &= 10 \text{ mbar}
 \end{aligned}$$

A pressure of 10 mbar, column 1, corresponds in Tab. L to an output of 450 kW.

This value serves as a rough guide; the effective output must be measured at the gas meter.

To calculate the required gas pressure at test point 1)(Fig. 26), set the maximum modulating output required from the burner operation:


- find the nearest output value in Tab. L for the burner in question.
- read, on the right (column 1), the pressure at the test point 1) (Fig. 26).
- Add this value to the estimated pressure in combustion chamber.

**Example:**

Operating at the desired maximum output: 450 kW

$$\begin{aligned}
 \text{Gas pressure at an output of 450 kW} &= 10 \text{ mbar} \\
 \text{Pressure in combustion chamber} &= 2 \text{ mbar} \\
 10 + 2 &= 12 \text{ mbar}
 \end{aligned}$$

pressure required at test point 1)(Fig. 26).



**Fig. 26**

**5.11 Electrical wiring**

**Notes on safety for the electrical wiring**



- The electrical wiring must be carried out with the electrical supply disconnected.
- Electrical wiring must be made in accordance with the regulations currently in force in the country of destination and by qualified personnel. Refer to the wiring diagrams.
- The manufacturer declines all responsibility for modifications or connections different from those shown in the wiring diagrams.
- Check that the electrical supply of the burner corresponds to that shown on the identification label and in this manual.
- The burner has been type-approved for intermittent use. This means they should compulsorily be stopped at least once every 24 hours to enable the control box to perform checks of its own start-up efficiency. Normally, burner stopping is guaranteed by the boiler's thermostat/pressure switch.
- The burner is factory set for FS1 operation (1 stop every 24 hours); it can be converted to FS2 operation (continuous - 1 stop every 72 hours), by changing the parameters using the menu of the AZL Display.
- The electrical safety of the device is obtained only when it is correctly connected to an efficient earthing system, made according to current standards. It is necessary to check this fundamental safety requirement. In the event of doubt, have the electrical system checked by qualified personnel. Do not use the gas tubes as an earthing system for electrical devices.
- The electrical system must be suitable for the maximum power absorption of the device, as indicated on the label and in the manual, checking in particular that the section of the cables is suitable for that level of power absorption.
- For the main power supply of the device from the electricity mains:
  - do not use adapters, multiple sockets or extensions;
  - make provisions for an omnipolar switch with a gap between the contacts of at least 3 mm (over-voltage category III), as required by current safety regulations.
- Do not touch the device with wet or damp body parts and/or in bare feet.
- Do not pull the electric cables.

Before carrying out any maintenance, cleaning or checking operations:



Turn off the burner's power supply using the main system switch.





Turn off the fuel interception tap.



Avoid condensate, ice and water leaks from forming.

If the cover is still present, remove it and proceed with the electrical wiring according to the wiring diagrams.

Use flexible cables in compliance with the EN 60 335-1 standard.



20104934

**Fig. 27**

**5.11.1 Supply cables and external connections passage**

All the cables to be connected to the plugs 6) of the burner are made to pass from the cable grommets supplied to be inserted in the holes of the plate, left or right (Fig. 27).

The use of the cable grommets and the pre-blanked holes can be done in different manners; by way of example we indicate the following mode:

- 1 single-phase power supply
- 2 Inverter control signals cable
- 3 Inverter motor power cable
- 4 Thermostat/Pressure switch TR
- 5 Thermostat/Pressure switch TL
- 6 PLL signals kit
- 7 Gas valves
- 8 Minimum gas pressure switch
- 9 Leak detection control
- 10 Available



After carrying out maintenance, cleaning or checking operations, reassemble the cover and all the safety and protection devices of the burner.

**6 Start-up, calibration and operation of the burner**

**6.1 Notes on safety for the first start-up**



The first start-up of the burner must be carried out by qualified personnel, as indicated in this manual and in compliance with the standards and regulations of the laws in force.



Check the correct working of the adjustment, command and safety devices.

**6.2 Adjustments prior to ignition**

The adjustments to be carried out are:

- Ensure that the gas supply company has carried out the supply line vent operations, eliminating air or inert gases from the piping.
- Slowly open the manual valves situated upstream from the gas train.
- Adjust the minimum gas pressure switch (Fig. 32 on page 30) to the start of the scale.
- Adjust the maximum gas pressure switch (Fig. 31 on page 29) to the end of the scale.
- Adjust the air pressure switch (Fig. 30 on page 29) to the start of the scale.
- Adjust the pressure switch for the valve leak detection control device (PVP kit) (Fig. 33 on page 30) if present, according to the instructions supplied with the kit itself.
- Check the gas supply pressure by connecting a pressure gauge to the pressure test point 1) (Fig. 28) of the minimum gas pressure switch: it must be lower than the maximum allowed pressure of the gas train, as shown on the characteristics label.




Excessive gas pressure can damage the components of the gas train and lead to a risk of explosion.

- Bleed the air from the piping of the gas train, connecting a plastic tube to the pressure test point 1) (Fig. 28) of the minimum gas pressure switch. Take the vent tube outside the building so you can notice the smell of gas.
- Connect two lamps or testers to the two gas line solenoids to check the exact moment in which voltage is supplied. This operation is unnecessary if each of the two solenoid valves is equipped with a pilot light that signals voltage passing through.



Before starting up the burner, it is good practice to adjust the gas train so that ignition takes place in conditions of maximum safety, i.e. with gas delivery at the minimum.



**Fig. 28**

**6.3 Burner start-up**

Feed electricity to the burner via the disconnecting switch on the boiler panel.

Close the thermostats/pressure switches and set the selector of Fig. 29 to "ON".



Make sure that the lights or testers connected to the solenoids, or the pilot lights on the solenoids themselves, indicate that no voltage is present.

If voltage is present, stop the burner immediately and check the electrical connections.

As the burner is not fitted with a phase sequence control device, the motor rotation may be incorrect.


As soon as the burner starts up, go in front of the cooling fan of the fan motor and check it is rotating anticlockwise. See Fig. 29.

If this is not the case:

- place the switch of Fig. 29 in position "0" and wait for the control box to carry out the switch-off phase;
- disconnect the burner from the electrical supply;
- invert the phases on the three-phase power supply.



This operation must be carried out with the electrical supply disconnected.



20104935

**Fig. 29**

**6.4 Burner adjustment**

**6.4.1 Output upon ignition**

According to EN 676.

**Burners with MAX output up to 120 kW**

Ignition can occur at the maximum operation output level.

Example:

- max. operation output: 120 kW
- max. ignition output: 120 kW

**Burners with MAX output above 120 kW**

Ignition must occur at a lower output than the max. operation output.

If ignition output does not exceed 120 kW, no calculations are required. If ignition output exceeds 120 kW, the regulatory standard sets that the value be defined according to the control box safety time "ts":

for "ts" = 3s, ignition output must be equal to, or lower than, 1/3 of max. operation output.

Example:

MAX operation output of 450 kW.

The ignition output must be equal to or less than 150 kW with ts = 3s

In order to measure the ignition output:

- remove the flame sensor from its housing 14)(Fig. 5 on page 13) (the burner comes on and goes into lockout after the safety time);
- perform 10 consecutive ignitions with lockouts;
- on the meter, read the quantity of gas burned: This quantity must be equal to, or lower than, the quantity given by the formula, for ts = 3s:

$$Vg = \frac{Qa \text{ (max. burner delivery)} \times n \times ts}{3,600}$$

- Vg** volume supplied in ignitions carried out (Sm<sup>3</sup>)
- Qa** ignition delivery (Sm<sup>3</sup>/h)
- n** number of ignitions (10)
- ts** safety time (sec)

**Example for gas G20 (9.45 kWh/Sm<sup>3</sup>):**

ignition output 150 kW - corresponding to 15.87 Sm<sup>3</sup>/h.

After 10 ignitions with their lockouts, the delivery indicated on the meter must be equal to or less than:

$$Vg = \frac{15.87 \times 10 \times 3}{3,600} = 0.132 \text{ Sm}^3$$

**6.4.2 Maximum output**

The MAX output must be set within the firing rate (Fig. 2 on page 10).

**Adjustment of gas delivery**

Measure the gas delivery on the gas meter.

As an indicative guide it can be taken from Tab. L on page 25, just read the gas pressure on the pressure gauge (shown in Fig. 37 on page 33) and follow the instructions given on pag. 25.

- If it is necessary to reduce it, lower the output gas pressure via the pressure adjuster located beneath the gas valve.
- If delivery needs to be increased, increase the adjuster outlet gas pressure.

**Air adjustment**

If necessary vary the degrees of the air servomotor.

**6.4.3 Minimum output**

The MIN output must be set within the firing rate (Fig. 2 on page 10).



**6.5 Final adjustment of the pressure switches**

**6.5.1 Air pressure switch**

Adjust the air pressure switch (Fig. 30) after performing all other burner adjustments with the air pressure switch set to the start of the scale.

With the burner operating at minimum output, insert a combustion analyser in the stack, slowly close the suction inlet of the fan (for example, with a piece of cardboard) until the CO value does not exceed 100 ppm.

Slowly turn the appropriate knob clockwise until the burner goes into lockout.

Check the indication of the arrow pointing upwards on the graduated scale. Turn the knob clockwise again, until the value shown on the graduated scale corresponds with the arrow pointing downwards, and so recovering the hysteresis of the pressure switch (shown by the white mark on a blue background, between the two arrows).


Now check the correct start-up of the burner. If the burner locks out again, turn the knob anti-clockwise a little bit more. During these operations it may be useful to measure the air pressure with a pressure gauge.

The connection of the pressure gauge is shown in Fig. 30. The standard configuration is that with the air pressure switch connected in absolute mode. Note the presence of a "T" connection, not supplied.

In certain applications in strong depression situations, the connection of the pressure switch does not allow it to change over.

In this case it is necessary to connect the pressure switch in differential mode, applying a second tube between the air pressure switch and the fan suction line mouth.

In this case also, the pressure gauge must be connected in differential mode, as shown in Fig. 30.



**Fig. 30**


**6.5.2 Maximum gas pressure switch**

Adjust the maximum gas pressure switch (Fig. 31) after performing all other burner adjustments with the maximum gas pressure switch set to the end of the scale.

With the burner operating at maximum output, lower the adjustment pressure by slowly turning the relative knob anticlockwise until the burner locks out.

Now turn the knob clockwise by 0,2 kPa (2 mbar) and repeat the start-up of the burner.

If the burner locks out again, turn the knob clockwise again by 0,1 kPa (1 mbar).



**Fig. 31**


**6.5.3 Minimum gas pressure switch**

Adjust the minimum gas pressure switch (Fig. 32) after performing all the other burner adjustments with the pressure switch set to the start of the scale.

With the burner operating at maximum output, increase adjustment pressure by slowly turning the relative knob clockwise until the burner stops.

Now turn the knob anticlockwise by 0,2 kPa (2 mbar) and repeat burner start-up to ensure it is uniform.

If the burner locks out again, turn the knob anticlockwise again by 0,1 kPa (1 mbar).




**Fig. 32**

**6.5.4 PVP pressure switch kit**

Adjust the pressure switch for the leak detection control (PVP kit) (Fig. 33) according to the instructions supplied with the kit.



1 kPa = 10 mbar



**Fig. 33**

**6.6 Ignition failure**

If the burner does not switch on, there is a lockout within 3s of the electrical supply reaching the gas valve.

It may be that the gas does not arrive at the combustion head within the safety time of 3s.

In this case increase gas ignition flow rate. The arrival of gas to the pipe coupling is displayed on the pressure gauge, as shown in (Fig. 37 on page 33).



In the event the burner stops, in order to prevent any damage to the installation, do not unblock the burner more than twice in a row.

If the burner locks out for a third time, contact the customer service.



In the event there are further lockouts or faults with the burner, the maintenance interventions must only be carried out by qualified, authorised personnel, in accordance with the contents of this manual and in compliance with the standards and regulations of current laws.

**6.7 Burner flame goes out during operation**


If the flame accidentally goes out during operation, the control box carries out a recycle (i.e. it repeats the start-up phase once, and makes a further ignition attempt).

If the flame is still absent, the control box goes into lockout.

**6.8 Stopping of the burner**

The burner can be stopped by:

- intervening on the disconnecting switch of the electrical supply line, located on the boiler panel;
- setting the selector on OFF;
- using the operating panel;
- removing the transparent protection that covers the Operating Panel, after taking out the relative screws, it is possible to access the AZL display to work on the various parameters of the control box.







**Fig. 34**

20104938



**6.9 Final checks (with burner operating)**

|   |   |   |
|---|---|---|
| <ul style="list-style-type: none"> <li>➤ Open the thermostat/pressure switch TL</li> <li>➤ Open the thermostat/pressure switch TS</li> </ul>  |  | The burner must stop                                    |
| <ul style="list-style-type: none"> <li>➤ Turn the gas maximum pressure switch knob to the minimum end of scale position</li> <li>➤ Turn the air pressure switch to the maximum end of scale position</li> </ul> |  | The burner must stop in lockout                         |
| <ul style="list-style-type: none"> <li>➤ Turn off the burner and cut off the power</li> <li>➤ Disconnect the minimum gas pressure switch connector</li> </ul>   |  | The burner must not start                               |
| <ul style="list-style-type: none"> <li>➤ Remove the flame sensor from its housing</li> </ul>  |  | The burner must stop in lockout due to ignition failure |

**Tab. M**



**WARNING**

Make sure that the mechanical locking systems on the various adjustment devices are fully tightened.

**7 Maintenance**

**7.1 Notes on safety for the maintenance**

The periodic maintenance is essential for the good operation, safety, yield and duration of the burner.

It allows you to reduce consumption and polluting emissions and to keep the product in a reliable state over time.



The maintenance interventions and the calibration of the burner must only be carried out by qualified, authorised personnel, in accordance with the contents of this manual and in compliance with the standards and regulations of current laws.

Before carrying out any maintenance, cleaning or checking operations:



Turn off the burner's power supply using the main system switch.



Turn off the fuel interception tap.



Wait for the components in contact with heat sources to cool down completely.

**7.2 Maintenance programme**

**7.2.1 Maintenance frequency**



The gas combustion system should be checked at least once a year by a representative of the manufacturer or another specialised technician.

**7.2.2 Checking and cleaning**



The operator must use the required equipment during maintenance.

**Combustion**

The optimum calibration of the burner requires an analysis of the flue gases.

Significant differences with respect to the previous measurements indicate the points where most care should be exercised during maintenance.

**Combustion head**

Open the burner and make sure that all components of the combustion head are in good condition, not deformed by the high temperatures, free of impurities from the surroundings, and that the relative materials are not corroded and that they are correctly positioned.

Check the gas outlet holes for the ignition phase (in the distributor of the combustion head) are free of impurities or rust. If in doubt, disassemble the elbow (Fig. 39 on page 34).

**Fan**


Check to make sure that no dust has accumulated inside the fan or on its blades, as this condition will cause a reduction in the air flow rate and provoke polluting combustion.

**Burner**

Clean the outside of the burner.

**Flame inspection window**

Clean the glass of the flame inspection window (Fig. 35).



**Fig. 35**

**Gas leaks**

Make sure that there are no gas leaks on the pipe between the gas meter and the burner.

**Gas filter**

Change the gas filter when it is dirty.

**Boiler**


Clean the boiler as indicated in its accompanying instructions in order to maintain all the original combustion characteristics intact, especially: the flue gas temperature and combustion chamber pressure.

**Voltage on the QRI cell**

Min value for a good work: 3.5V DC (value on AZL display at about 50%) (Fig. 36).

If the value is lower, it could be due to:

- cell not positioned correctly
- low voltage (less than 187 V)
- bad regulation of the burner



**Fig. 36**

**Combustion**

In case the combustion values found at the beginning of the intervention do not respect the standards in force or, in any case, do not correspond to a proper combustion, contact the Technical Assistance Service in order to carry out the necessary adjustments.

| EN 676 |   | Air excess                         |                                    | CO      |
|--------|---|------------------------------------|------------------------------------|---------|
|        |   | Max. output.<br>$\lambda \leq 1.2$ | Max. output.<br>$\lambda \leq 1.3$ |         |
| GAS    | Theoretical<br>max CO <sub>2</sub><br>0% O <sub>2</sub> | CO <sub>2</sub> % Calibration      |                                    | mg/kWh  |
|        |   | $\lambda = 1.2$                    | $\lambda = 1.3$                    |         |
| G 20   | 11.7  | 9.7                                | 9                                  | ≤ 1,000 |
| G 25   | 11.5  | 9.5                                | 8.8                                | ≤ 1,000 |
| G 30   | 14.0  | 11.6                               | 10.7                               | ≤ 1,000 |
| G 31   | 13.7  | 11.4                               | 10.5                               | ≤ 1,000 |

Tab. N

**7.2.3 Checking the air and gas pressure on the combustion head**

To carry out this operation it is necessary to use a pressure gauge to measure the air and gas pressure at the combustion head, as shown in Fig. 37.




Fig. 37

**7.2.4 Moving backward of the control box**



Turn off the burner's power supply using the main system switch.

This system allows to move backward the cam of about 100 mm using the appropriate slide bars obtained in the holder.

- Loosen the locking screw 1) (Fig. 38);
- Through the handle 2), move backward the cam enough to reach the internal wiring harness. At the end of this operation, restore the starting position and tighten the locking screw.




Fig. 38

### 7.3 Opening the burner



Turn off the burner's power supply using the main system switch.




Turn off the fuel interception tap.



Wait for the components in contact with heat sources to cool down completely.

- Loosen the screw 1)(Fig. 39) and remove the cover 2).
- Disconnect the plug of the gas servomotor.
- Remove screw 5)(Fig. 39) and pull the burner back of about 100 mm on the slide bars 6).
- Remove the electrode cable and then draw back the entire burner.
- At this point it is possible to extract the inner part 7) after having removed the screw 8).



20105229

Fig. 39

### 7.4 Closing the burner

- Once carry out the maintenance, reassemble the internal part 7) by locking the screw 8).
- Push the burner until it is approx. 100 mm from the pipe coupling (Fig. 39).
- Reconnect the cables that were previously disconnected and slide in the burner until it comes to a stop.
- Connect the servomotor plug.
- Replace the screw 5)(Fig. 39) and carefully pull the electrode cable outwards until slightly taut.



After carrying out maintenance, cleaning or checking operations, reassemble the cover and all the safety and protection devices of the burner.

**8** **Faults - Possible causes - Solutions**

If faults arise in ignition or operations, the burner performs a "safety stop", which is signalled by the red burner lockout LED.

The display visualises alternately the lockout code and the relative diagnostic. To reset the start-up conditions, refer to the "Reset procedure" indicated in the control box manual supplied.

When the burner starts again, the red LED goes out and the control box is reset.



**WARNING**

In the event the burner stops, in order to prevent any damage to the installation, do not unblock the burner more than twice in a row. If the burner locks out for a third time, contact the customer service.



**DANGER**

In the event there are further lockouts or faults with the burner, the maintenance interventions must only be carried out by qualified, authorised personnel, in accordance with the contents of this manual and in compliance with the standards and regulations of current laws.

**A Appendix - Accessories****Spacer kit**

| Burner   | Thickness (mm) | Code    |
|----------|----------------|---------|
| RS 50/EV | 100            | 3010095 |

**Connection flange kit**

| Burner   | Code    |
|----------|---------|
| RS 50/EV | 3010138 |

**Kit for LPG operation**

| Burner   | Output kW     | Code     |
|----------|---------------|----------|
| RS 50/EV | 125/285 - 630 | 20008173 |

**Town gas kit**

| Burner   | Output kW     | Code    |
|----------|---------------|---------|
| RS 50/EV | 116 - 290/581 | 3010285 |

**Software interface kit**

| Burner   | Code    |
|----------|---------|
| RS 50/EV | 3010388 |

**Kit PVP (Pressure Valve Proving)**

| Burner   | Gas train type | Code    |
|----------|----------------|---------|
| RS 50/EV | MB - CB        | 3010344 |

**Probe for checking temperature/pressure**

| Parameter to be checked |                  | Probe        |         |
|-------------------------|------------------|--------------|---------|
|                         | Adjustment field | Type         | Code    |
| Temperature             | - 100...+ 500°C  | PT 100       | 3010110 |
| Pressure                | 0...2.5 bar      | Output probe | 3010213 |
|                         | 0...16 bar       | 4....20 mA   | 3010214 |

**Probe for checking the air/combustion fume temperature**

| Parameter to be checked |                  | Probe          |         |
|-------------------------|------------------|----------------|---------|
|                         | Adjustment field | Type           | Code    |
| Temperature             | - 100...+ 500°C  | PT 1000/Ni1000 | 3010377 |

**Gas trains in compliance with EN 676**

Please refer to manual.


**B Appendix - Electrical panel layout**

|           |   |
|-----------|---|
| <b>1</b>  | <b>Index of layouts</b>                 |
| <b>2</b>  | Indication of references                |
| <b>3</b>  | Layout of unifilar output               |
| <b>4</b>  | LMV52 ...operational layout             |
| <b>5</b>  | LMV52 ...operational layout             |
| <b>6</b>  | LMV52 ...operational layout             |
| <b>7</b>  | LMV52 ...operational layout             |
| <b>8</b>  | LMV52 ...operational layout             |
| <b>9</b>  | LMV52 ...operational layout             |
| <b>10</b> | LMV52 ...operational layout             |
| <b>11</b> | PLL52.../QG020.. operational layout     |
| <b>12</b> | Electrical connections set by installer |
| <b>13</b> | Electrical connections set by installer |

**2 Indication of references**








|                                       |  |                                 |  |
|---------------------------------------|--|---------------------------------|--|
| BU = BLU / BLUE / BLEU / BLAU         | WH = BIANCO / WHITE / BLANC / WEISS      | GY= GRIGIO / GREY / GRIS / GRAU | TO= TURCHESE / TURQUOISE / TURKOISE / TURKISBLAU         |
| BK = NERO / BLACK / NOIR / SCHWARZ    | OG= ARANCIO / ORANGE / ORANGE / ORANGE   | PK= ROSA / PINK / ROSE / ROSA   | SR= ARGENTO / SILVER / ARGENT / SILBER                   |
| BN = MARRONE / BROWN / MARRON / BRAUN | VT= VIOLETTO / VIOLET / VIOLET / VIOLETT | GD= ORO / GOLD / OR / GOLD      | GN= GIALLO/VERDE / YELLOW/GREEN / JAUNE/VERT / GELB/GRUN |
| YE = GIALLO / YELLOW / JAUNE / GELB   |  |                                 |  |
| GN = VERDE / GREEN / VERT / GRUN      |  |                                 |  |
| RD = ROSSO / RED / ROUGE / ROT        |  |                                 |  |

SCHEMA FUNZIONALE LMV52...      LMV52... OPERATIONAL LAYOUT      BETRIEBSSCHEMA LMV52...      SCHEMA FONCTIONNEL LMV52...      Sheet : 4







|                                       |                                     |   |                                  |   |
|---------------------------------------|-------------------------------------|---|----------------------------------|---|
| BU = BLU / BLUE / BLEU / BLAU         | YE = GIALLO / YELLOW / JAUNE / GELB | WH = BIANCO / WHITE / BLANC / WEISS       | GY = GRIGIO / GREY / GRIS / GRAU | TO = TURCHESE / TURQUOISE / TURKOISE / TURKISBLAU           |
| BK = NERO / BLACK / NOIR / SCHWARZ    | GN = VERDE / GREEN / VERT / GRÜN    | OG = ARANCIO / ORANGE / ORANGE / ORANGE   | PK = ROSA / PINK / ROSE / ROSA   | SP = ARGENTO / SILVER / ARGENT / SILBER                     |
| BN = MARRONE / BROWN / MARRON / BRAUN | RD = ROSSO / RED / ROUGE / ROT      | VT = VIOLETTA / VIOLET / VIOLET / VIOLETT | GD = ORO / GOLD / OR / GOLD      | GNYE = GIALLO/VERDE / YELLOW/GREEN / JAUNE/VERT / GELB/GRÜN |

SCHEMA FUNZIONALE LMV52... OPERATIONAL LAYOUT

BETRIEBSSCHEMA LMV52...


SCHEMA FONCTIONNEL LMV52...






|                                       |                                     |   |                                  |   |
|---------------------------------------|-------------------------------------|---|----------------------------------|---|
| BU = BLU / BLUE / BLEU / BLAU         | YE = GIALLO / YELLOW / JAUNE / GELB | WH = BIANCO / WHITE / BLANC / WEISS       | GY = GRIGIO / GREY / GRIS / GRAU | TO = TIRCHESE / TURQUOISE / TURKOISE / TURKISBLAU           |
| BK = NERO / BLACK / NOIR / SCHWARZ    | GN = VERDE / GREEN / VERT / GRÜN    | OG = ARANCIO / ORANGE / ORANGE / ORANGE   | PK = ROSA / PINK / ROSE / ROSA   | SR = ARGENTO / SILVER / ARGENT / SILBER                     |
| BN = MARRONE / BROWN / MARRON / BRAUN | RD = ROSSO / RED / ROUGE / ROT      | VI = VIOLETTA / VIOLET / VIOLET / VIOLETT | GD = ORO / GOLD / OR / GOLD      | GNYE = GIALLO/VERDE / YELLOW/GREEN / JAUNE/VERT / GELB/GRÜN |


SCHEMA FUNZIONALE LMV52... SCHEMA FONCTIONNEL LMV52... SCHEMA FUNCTIONNEL LMV52...  
 LMV52... OPERATIONAL LAYOUT  
 BETRIEBSSCHEMA LMV52...  
 SCHEMA FONCTIONNEL LMV52...  
 Sheet : 8











NEL CASO DI INTERRUPTORE DIFFERENZIALE SCEGLIERE IL TIPO B I=300mA IL NEUTRO DEVE ESSERE A TERRA IL CAVO DI ALIMENTAZIONE MOTORE DEVE ESSERE LUNGO MAX. 25m

NEL CASO DI INTERRUPTORE MAGNETOTERMICO SCEGLIERE IL TIPO C WITH A MAGNETO-THERMAL SWITCH CHOOSE TYPE C EN CAS D'INTERRUPTEUR MAGNÉTO-THERMIQUE CHOISIR LE TYPE C IM FALLE EINES MAGNETOTHERMISCHEN SCHALTERS TYP C WÄHLEN

WITH A DIFFERENTIAL SWITCH CHOOSE TYPE B I=300mA THE NEUTRAL MUST BE EARTHED DAS MOTORSTROMKABEL DARF MAX. 25m LANG SEIN

WITH A DIFFERENTIAL SWITCH CHOOSE TYPE B I=300mA THE NEUTRAL MUST BE EARTHED DAS MOTORSTROMKABEL DARF MAX. 25m LANG SEIN

EN CAS D'INTERRUPTEUR DIFFÉRENTIEL CHOISIR LE TYPE B I=300mA LE NEUTRE DOIT ÊTRE AU SOL LE CÂBLE D'ALIMENTATION DU MOTEUR DOIT AVOIR UNE LONGUEUR MAX. DE 25m

IM FALLE EINES DIFFERENTIALSCHALTERS TYP B I=300mA WÄHLEN DER NULLEITER MUSS GEEDET SEIN DAS MOTORSTROMKABEL DARF MAX. 25m LANG SEIN

max 10A AC1 230V AC

max 2A AC15 230V AC

INDICATORS/ANCILLARIES

TRIGGERING/SAFETY DEVICES

GAS VALVE+PVP LEAK DETECTION

BU = BLU / BLUE / BLEU / BLAU

BK = NERO / BLACK / NOIR / SCHWARZ

BN = MARRONE / BROWN / MARRON / BRAUN

YE = GIALLO / YELLOW / JAUNE / GELB

GN = VERDE / GREEN / VERT / GRÜN

RD = ROSSO / RED / ROUGE / ROT

WH = BIANCO / WHITE / BLANC / WEISS

OG = ARANCIO / ORANGE / ORANGE / ORANGE

VI = VIOLETTA / VIOLET / VIOLET / VIOLETT

GY = GRIGIO / GREY / GRIS / GRAU

PK = ROSA / PINK / ROSE / ROSA

GD = ORO / GOLD / OR / GOLD

TO = TURCHESE / TURKHOISE / TURKISBLAU

SR = ARGENTO / SILVER / ARGENT / SILBER

GNYE = GIALLO/VERDE / YELLOW/GREEN / JAUNE/VERT / GELB/GRÜN


COLLEGAMENTI ELETTRICI A CURA DELL'INSTALLATORE

ELECTRICAL CONNECTIONS SET BY INSTALLER

ELEKTROANSCHLÜSSE VOM INSTALLATEUR AUSZUFÜHREN

RACCORDMENTS ÉLECTRIQUE EFFECTUÉ PAR L'INSTALLATEUR

Sheet : 12



BU = BLU / BLUE / BLEU / BLAU  
 BK = NERO / BLACK / NOIR / SCHWARZ  
 BN = MARRONE / BROWN / MARRON / BRAUN  
 YE = GIALLO / YELLOW / JAUNE / GÉLB  
 GN = VERDE / GREEN / VERT / GRÜN  
 BK = ROSA / PINK / ROSE / ROSA  
 GN = GRIGIO / GREY / GRIS / GRAU  
 PK = ROSA / PINK / ROSE / ROSA  
 GD = ORO / GOLD / OR / GOLD  
 WH = BIANCO / WHITE / BLANC / WEISS  
 DG = ARANCIO / ORANGE / ORANGE / ORANGE  
 VT = VIOLETTO / VIOLET / VIOLET / VIOLETT  
 TO = TURCHESE / TURQUOISE / TURKUISE / TURKISBLAU  
 SR = ARGENTO / SILVER / ARGENT / SILBER  
 GNYE = GIALLO/VERDE / YELLOW/GREEN / JAUNE/VERT / GELB/GRÜN

COLLEGAMENTI ELETTRICI A CURA DELL' INSTALLATORE ELECTRICAL CONNECTIONS SET BY INSTALLER ELEKTROANSCHLÜSSE VOM INSTALLATEUR AUSZUFÜHREN RACCORDEMENTS ÉLECTRIQUE EFFECTUÉ PAR L' INSTALLATEUR

**Wiring layout key**

|       |  |    |   |
|-------|--|----|---|
| A5    | Control box  | X1 | Main supply terminal board              |
| B     | Protection against radio interference                        | X2 | Secondary terminal board                |
| B1    | Internal RWF50 output power regulator                        | Y  | Gas adjustment valve + gas safety valve |
| B2    | External RWF50 output power regulator                        |    |   |
| BA1   | Output device in current to modify remote setpoint           |    |   |
| BP    | Pressure probe   |    |   |
| BP1   | Pressure probe   |    |   |
| BR    | Remote setpoint voltage divider                              |    |   |
| BT1   | Thermocouple probe   |    |   |
| BT2   | Probe Pt100, 2 wires   |    |   |
| BT3   | Probe Pt100, 3 wires   |    |   |
| BT4   | Probe Pt100, 3 wires   |    |   |
| BTEXT | External probe for the climatic compensation of the setpoint |    |   |
| BV    | Output probe in voltage                                      |    |   |
| BV1   | Output device in voltage to modify remote setpoint           |    |   |
| F2    | Fuse for inverter power supply                               |    |   |
| F3    | Auxiliary fuse   |    |   |
| H1    | Light signalling burner on                                   |    |   |
| H2    | Heat request lighting signal                                 |    |   |
| H3    | Burner working lighting signal                               |    |   |
| KL1   | Direct start and star/delta starter line contactor           |    |   |
| KT1   | Star-powered/delta-powered starter /delta contactor          |    |   |
| KS1   | Star-powered/delta-powered starter /star-powered contactor   |    |   |
| KST1  | Star-powered/delta -powered starter timer                    |    |   |
| K2    | Clean contacts output relay motor lockout                    |    |   |
| K3    | Clean contacts output relay for burner lockout               |    |   |
| K6    | Clean contacts output relay burner switched on               |    |   |
| IN    | Switch for manual shut-off burner                            |    |   |
| MV    | Fan motor  |    |   |
| PA    | Air pressure switch  |    |   |
| PE    | Burner earth   |    |   |
| PGMax | Maximum gas pressure switch                                  |    |   |
| PGMin | Minimum gas pressure switch                                  |    |   |
| PGVP  | Gas pressure switch for valve leak detection control device  |    |   |
| RS    | Remote burner reset button                                   |    |   |
| S2    | ON/OFF selector  |    |   |
| S4    | LOCAL-REMOTE selector  |    |   |
| PS    | Burner reset button and lock-out signal                      |    |   |
| SM    | Servomotor   |    |   |
| TA    | Ignition transformer   |    |   |
| TL    | Limit thermostat/pressure switch                             |    |   |
| TS    | Safety thermostat/pressure switch                            |    |   |
| TR    | Control pressure switch/thermostat                           |    |   |
| UV    | Flame sensor   |    |   |
| YVPS  | Gas valve leak detection control device                      |    |   |
| XAZL  | Plug for on-board AZL  |    |   |
| XPLL  | Terminal board for PLL kit                                   |    |   |
| XRWF  | Terminal board for RWF50                                     |    |   |
| XSM   | Servomotor connector   |    |   |
| XSM1  | Servomotor connector (auxiliary)                             |    |   |

---

**RIELLO**

RIELLO S.p.A.  
I-37045 Legnago (VR)  
Tel.: +39.0442.630111  
[http:// www.riello.it](http://www.riello.it)  
[http:// www.riello.com](http://www.riello.com)